



# Installation Instructions

By: Andrea Tobar

COMPREHENSIVE Final Edit

LightingSaving  
www.LS-Photostudio.com

1. Open your package and check that the items are all included in the package.




- \* 1x High quality photo studio tent
- \* 4x Non-reflective background (red/black/blue/white)
- \* 1 High quality output light stand
- \* 1 Tripod

Components may vary based on your purchase order number

2. Unfold the two covers upward with the single panel on the left and the double panel on the right.

3. Turn the black cover facing toward you.



4. Unfold the right cover upward to stick along the velcro edge of the left cover, pressing the velcro edge with your fingers to firm the tent.



5. Attach the background of your desired color along the inside velcro edge.



6. Unfold the legs of the light stand and adjust to the desired height.



(More photos of our light stands at [www.LS-Photostudio.com](http://www.LS-Photostudio.com))

WARNING: Do not touch the lighting head because it can get very hot.

WARNING: Do not use over one hour.



(More photos of our tripods at [www.LS-Photostudio.com](http://www.LS-Photostudio.com))



# Julius Studio Portable Light Installation


## (L02, L022)

---

1. Open your package and check that the item is included in the package.

\* 1 x Portable photography light with lightbulb

2. Pull the three tripod legs toward the floor.



2. Unscrew the cover from the front of the light.




3. Take off the cover.



4. Take out the lightbulb by unscrewing it counterclockwise carefully.



5. Place the new lightbulb in the socket, and turn the lightbulb clockwise until firm.



6. Replace the cover to the front of the light.



### How to change the lightbulb

1. Unplug the device before you change the lightbulb and wait until it is cool to avoid injury.

⊕r 3. Adjust each tripod leg to the desired position.